

Telephone:  
Fax:  
VAT Registration No.:


**Name:** Jorge Gil  
**Address:**  
**Tel - Private:**  
**Tel - Business:**  
**Tel - Mobile:**


**Manufacturer:** Toyota  
**Model:** Yaris  
**Year:** 2000  
**Registration:**  
**Mileage:**  
**Job number:**  
**Date:**

|        |  |
|--------|--|
| A63    | AC control module                                |
| G1     | Alternator                                       |
| C3     | Audio unit suppressor                            |
| 31     | Battery -  |
| 30     | Battery +  |
| S13    | Brake pedal position (BPP) switch                |
| Y81    | Camshaft position (CMP) actuator                 |
| B132   | Camshaft position (CMP) sensor                   |
| B54    | Crankshaft position (CKP) sensor                 |
| X1     | Data link connector (DLC)                        |
| A35    | Engine control module (ECM)                      |
| K46    | Engine control relay                             |
| B24    | Engine coolant temperature (ECT) sensor          |
| H63    | Engine malfunction indicator lamp (MIL)          |
| Y104   | Evaporative emission (EVAP) canister purge valve |
| M12    | Fuel pump  |
| K20    | Fuel pump relay                                  |
| F      | Fuse   |
| X28-II | Fuse box/relay plate - engine bay 1              |
| X28-I  | Fuse box/relay plate - fascia 1                  |
| B72    | Heated oxygen sensor (HO2S)                      |
| Y56    | Idle speed control (ISC) actuator                |
| T1     | Ignition coil                                    |
| 15     | Ignition switch - ignition ON                    |
| 50     | Ignition switch - start signal                   |
| Y3     | Injector   |
| A5     | Instrument panel                                 |
| A75    | Instrumentation control module                   |
| B69    | Knock sensor (KS)                                |
| B30    | Mass air flow (MAF) sensor                       |
| B157   | Power steering pressure (PSP) sensor             |
| B147   | Throttle position (TP) sensor                    |
| S249   | Transmission range (TR) switch                   |

|                   |                  |                          |              |
|-------------------|------------------|--------------------------|--------------|
| bl = blue         | br = brown       | el = cream               | ge = yellow  |
| gn = green        | gr = grey        | nf = neutral             | og = orange  |
| rs = pink         | rt = red         | sw = black               | vi = violet  |
| ws = white        | hbl = light blue | hgn = light green        | rbr = maroon |
| x = braided cable | y = high tension | z = non-cable connection |              |

**NOTE:** In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.





37741

EP1